

# Self-Loop Rule

Now consider the equation:

$$b_1 = \alpha a_1 + \beta a_2 + \gamma b_1$$

A little dab of **algebra** allows us to determine the value of node  $b_1$ :


$$b_1 = \alpha a_1 + \beta a_2 + \gamma b_1$$

$$b_1 - \gamma b_1 = \alpha a_1 + \beta a_2$$

$$(1 - \gamma) b_1 = \alpha a_1 + \beta a_2$$


$$b_1 = \frac{\alpha}{1 - \gamma} a_1 + \frac{\beta}{1 - \gamma} a_2$$

The signal flow graph of the **first** equation is:



While the signal flow graph of the **second** is:

$$b_1 = \frac{\alpha}{1-\gamma} a_1 + \frac{\beta}{1-\gamma} a_2$$




These two signal flow graphs are **equivalent!**

Note the self-loop has been "**removed**" in the second graph. Thus, we now have a method for removing self-loops. This method is **rule 3**.

### Rule 3 - Self-Loop Rule

*A self-loop can be eliminated by multiplying **all** of the branches "**feeding**" the self-loop node by  $1/(1 - S_{sl})$ , where  $S_{sl}$  is the value of the self loop branch.*

For example:




can be simplified by **eliminating the self-loop**.


We multiply **both** of the two branches **feeding** the self-loop node by:

$$\frac{1}{1 - S_{sl}} = \frac{1}{1 - 0.2} = 1.25$$

Therefore:




And thus:




Or another example:

$$a_1 = 0.06 a_1 - j b_2$$

$$b_1 = 0.3 a_1$$



becomes after reduction using rule 3:



**Q:** Wait a minute! I think you *forgot* something. Shouldn't you **also** divide the 0.3 branch value by  $1 - 0.06 = 0.94$ ??



**A:** Nope! The 0.3 branch is **exiting** the self-loop node  $a_1$ . **Only** incoming branches (e.g., the  $-j$  branch) to the self-loop node are modified by the self-loop rule!